


## Translation of the original instructions

Switching device with inductive transmission system used in combination with safety edges to avoid dangers at crushing and shearing points in sliding gate systems.


### Safety and warning notices

- The electrical connection may only be set up by an electrician. → The arrangement of the components depends on the structural conditions and the gate design. → Switch off the operating voltage before working on the system. → The switching device monitors pressure-sensitive protective devices from Bircher Reglomat AG (proper use). → Use of components not supplied by Bircher-Reglomat (including safety edges) will render the guarantee and liability null and void. → Connect all operating and switching voltages to the same fuse. → Connect the operating voltage to the same circuit as the industrial door controller. → Disconnect device from mains in the event of a fault. → Protection max. 10 A

### 1 System components



- ① Mobile safety edge CLOSE (primary closing edge)
- ② Mobile safety edge OPEN
- ③ Stationary safety edge CLOSE
- ④ Stationary safety edge OPEN
- ⑤ INTR-MOB61, converter for safety edge ①
- ⑥ INTR-MOB62, converter for mobile safety edge ②
- ⑦ INTR-FIX60, coil
- ⑧ InTra6 3, switching device
- ⑨ Steel cable (see chapter 9.3)



### 2 Electrical connection and terminal diagram



| Version                   | Operating voltage | Stationary safety edge CLOSE ③ | Stationary safety edge OPEN ④ | Coil connection ⑦          | Output CLOSE* | Output OPEN* |
|---------------------------|-------------------|--------------------------------|-------------------------------|----------------------------|---------------|--------------|
| InTra6 3<br>InTra6 3.LVAC | +/- A1<br>-/- A2  |                                |                               | YE RX<br>GN<br>WH TX<br>BN | 14<br>11      | 24<br>21     |

\* The outputs are monitored → need to be connected, otherwise an error code is displayed (E007)!

### 3 Operation



#### Display



### 4 Standard operation

When everything is connected correctly:

Display after switching on: Status LED lights up green

Displays shown when safety edge is actuated: Status LED lights up orange



### 5 Diagnostic menu

Press the «Mode» and «Data» buttons simultaneously for 2 s → status LED flashes orange. Press «Mode» buttons briefly to change to the next mode. Press the «Mode» button for 2 s to exit diagnostic menu.

#### Error display mode

The 5 most recent errors can be interrogated. Press the «Data» key briefly in each case, and the errors are displayed one after the other. End appears when the «Data» button is pressed for the 5th time. The malfunctions are displayed in chronological order (new → old)

#### Mode «r» Resistance

The resistances of the safety edges are displayed. Example: 8 = Resistance between 7 and 9 kohm. 1 = safety edge ①. To access the next safety edge: Press the «Data» button

#### Mode «S» Output CLOSE

- CLOSE output is deactivated - No current flow → OK  
 - Current flow → error  
 - Press the «Data» button  
 - CLOSE output is activated - Current flow → OK  
 - No current flow → Error (consumer missing)

#### Mode «S» Output OPEN

- OPEN output is deactivated - No current flow → OK  
 - Current flow → error  
 - Press the «Data» button  
 - OPEN output is activated - Current flow → OK  
 - No current flow → Error (consumer missing)

#### Mode «S» Both outputs

- Both outputs deactivated - No current flow → OK  
 - At least 1 output with current flow → Error - Press the «Data» button  
 - Both outputs are activated - Current flow → OK  
 - At least 1 output without current flow → Consumer missing


#### Mode «C» current configuration

Displays current configuration of safety edge inputs, see configuration table. Configuration → chapter 6

#### Mode «h» current fall-delay time


Displays current fall-delay time, see fall-delay time table. Configuration → chapter 6. To access the configuration mode: Press the «Mode» button

## 6 Configuration mode (for configuration before starting up, via diagnostic menu, after mode «h»)

 Please read chapters 6.1 to 6.3 in full before attempting configuration.


### 6.1 Activating configuration menu


 Status LED flashes orange, press «Data» button

 Press the «Mode» and «Data» buttons simultaneously for 2 s. Configuration menu is activated.

Configuration menu can be **exited** at any time by pressing the «Mode» button (2 s). «End» is displayed → Press «Data» button and release → Restart undertaken with new configuration.

### 6.2 Configuration of safety edge inputs


 The current setting for the safety edge inputs is displayed.

 Use the «Data» button to set the **configuration** you want for the safety edge inputs (according to Table 1).


| Display     | Mobile safety edge CLOSE ① | Mobile safety edge OPEN ② | Stationary safety edge CLOSE ③ | Stationary safety edge OPEN ④ |
|-------------|----------------------------|---------------------------|--------------------------------|-------------------------------|
| <i>unc</i>  | not configured             |                           |                                |                               |
| <i>001*</i> | X                          |                           | X                              | X                             |
| <i>002</i>  | X                          | X                         | X                              | X                             |
| <i>003</i>  |                            |                           | X                              | X                             |
| <i>004</i>  | X                          | X                         |                                |                               |
| <i>005</i>  | X                          |                           |                                |                               |
| <i>006</i>  | X                          | X                         | X                              |                               |
| <i>007</i>  | X                          | X                         |                                | X                             |
| <i>008</i>  | X                          |                           | X                              |                               |
| <i>009</i>  | X                          |                           |                                | X                             |
| <i>010</i>  |                            |                           | X                              |                               |
| <i>011</i>  |                            |                           |                                | X                             |

Table 1

\*) Factory setting

 Error messages may occur when restarting after configuration if the inputs do not match the configuration.

### 6.3 Configuration fall-delay time

 Press the «Mode» button briefly. Use the «Data» button to set the required **fall-delay time** (according to Table 2). Then briefly press the «Mode» button and End appears.

 End

- The system is configured.
- Press «Data» button to restart.

| Display     | Fall-delay time |
|-------------|-----------------|
| <i>001</i>  | none            |
| <i>002</i>  | 100 ms          |
| <i>003*</i> | 200 ms          |
| <i>004</i>  | 500 ms          |
| <i>005</i>  | 1000 ms         |

Table 2

\*) Factory setting

## 7 Error displays

 If an error is detected then the outputs are deactivated and symbols ① & ② and an error code are displayed. The status LED lights up red.

| Display       | E001                           | E002              | E003              | E004              | E005                        | E006                   | E007                         | E101/ E102                |
|---------------|--------------------------------|-------------------|-------------------|-------------------|-----------------------------|------------------------|------------------------------|---------------------------|
| <b>Error</b>  | Safety edge (SE) malfunction ① | SE mal-function ① | SE mal-function ① | SE mal-function ① | Cable circuit malfunction   | Mounting ≠config. mode | Outputs not OK               | Undervoltage/ overvoltage |
| <b>Remedy</b> | Check safety edge ①            | Check SE ②        | Check SE ③        | Check SE ④        | Check cable circuit < 3 ohm | Check configuration    | Check connection for outputs | Check supply              |

Should other fault messages appear, please contact your supplier.

## 8 Most important technical data

|                   |               |                          |         |  |
|-------------------|---------------|--------------------------|---------|--|
| Operating voltage | InTra6 3      | 24 V AC/DC ± 15%,        | Outputs | Semiconductor relay, 24 V DC, max. 50 mA |
|                   | InTra6 3.LVAC | 100-240 V AC<br>50/60 Hz |         | Dimensions (W x H x D)                   |
| Power consumption | max. 3 VA     |                          |         |  |
| Safety edges      | 8,2 kOhm      |                          |         |  |

## 9 Mounting






### 9.1 Electrical installation











1. Check that electrical components are all present by referring to component list 9.3.
2. Mount switching device in designated position.
3. Mounting of mechanical parts (see chapters 9.2 and 9.3).
4. Connect electrical lines as shown in terminal diagram in chapter 2.

### 9.2 Mechanical mounting


1. Check that mechanical components are all present by referring to component list 9.3
2. Mount the two mounting brackets ⑩ and the coil ⑦.
3. Pull in the steel cable (see chapter 9.4 and 9.5). Mount converter INTR-MOB ⑤ or ⑥.
4. Tension the steel cable ⑨ cable and fix it via the retaining screw ⑱. **The steel cable ⑨ must be able to move unimpeded through the INTR-FIX60 coil ⑦ along the full length of the gate.**
5. Connect steel cable ⑨ as described in chapter 9.5. Make sure the connection with the gate offers low resistance (clean the contact points and remove any paint).
6. Establish the electrical connection as shown in the terminal diagram in chapter 2.

### 9.3 List of electrical components


| Components                | Image   | Qty    | No. | Function  |
|---------------------------|---|--------|-----|---|
| INTR-MOB61 (grey)         |  | 1      | ⑤   | Converter, mobile sensor unit, transmits sensor status of primary closing edge                  |
| INTR-MOB62 (red)          |  | evt. 1 | ⑥   | Converter, mobile sensor unit, transmits sensor status of mobile secondary closing edge         |
| INTRA6 3 switching device |  | 1      | ⑧   | Evaluation and switching device   |
| INTR-FIX                  |  | 1      | ⑦   | Coil, transmits energy and information  |
| Steel cable               |  | 1      | ⑨   | Steel cable, forms the low-resistance cable circuit together with the gate structure (< 3 ohm!) |

| INTR-ASK60 components  |   |   |   |   |
|--|---|---|---|---|
| Mounting bracket   |    | 2 | ⑩ | For fastening the cable to the gate                                 |
| Banjo bolt, smooth, 8x60 with steel cable fixing screw (M4x10) |    | 1 | ⑪ | Part of cable tensioning device                                     |
| Banjo bolt   |    | 1 | ⑫ | Part of cable tensioning device                                     |
| Cable lug 2.5 mm <sup>2</sup>                                  |    | 2 | ⑬ | For connecting steel cable to gate                                  |
| Compression spring   |    | 1 | ⑭ | Part of cable tensioning device                                     |
| Hexagon bolt M6x12 including washer                            |   | 6 | ⑮ | For fastening bracket / cable to gate                               |
| Hexagon nut M6   |  | 2 | ⑯ | Part of cable tensioning device (on banjo bolt)                     |
| Plastic sleeve   |  | 2 | ⑰ | For insulation between banjo bolt / hollow pin and mounting bracket |
| U-shaped washer for M8   |  | 2 | ⑱ | Part of cable tensioning device (on banjo bolt)                     |
| Screw M4 x 10  |  | 2 | ⑲ | For fixing the cable in the banjo bolt / hollow pin                 |


### 9.4 Arrangement on a gate (example)



## 9.5 Mounting steel cable



## 9.6 Mounting substructure



## 10 EC Declaration of conformity, date of production

### 10.1 EC Declaration of conformity

|   |  |
|---|--|
| Manufacturer:                                     | Bircher Reglomat AG, Wiesengasse 20, CH-8222 Beringen                                      |
| Employee responsible for documentation:           | Bircher Reglomat GmbH, Dr. Marc Loschonsky, Robert-Bosch-Strasse 3, DE-71088 Holzgerlingen |
| Product:  | Inductive signal transmission system, switching device                                     |
| Models:   | InTra6 2, InTra6 3   |
| Notified Body:                                    | Suva, Bereich Technik, SCESp 008, Kenn-Nr. 1246  |
| Type-examination certificate:                     | E 6934, E 6935   |
| Fulfills the essential requirements in acc. with: | 2006/42/EG, 1999/5/EG  |
| Following standards were applied:                 | EN ISO 13849-1:2008+AC:2009  |
| Signee:   | CTO Dr. Marc Loschonsky, COO Daniel Nef  |

### 10.2 Date of production

See shield → week/year, e.g. 12/10 = week 12, 2010

## 11 Contact data

**Authorised representative:**  
**Bircher Reglomat GmbH**  
**Robert-Bosch-Strasse 3**  
**D-71088 Holzgerlingen**  
**Germany**  
**www.bircher-reglomat.com**

**Manufacturer:**  
**Bircher Reglomat AG**  
**Wiesengasse 20**  
**CH-8222 Beringen**  
**Switzerland**  
**www.bircher-reglomat.com**