370058C

07/19


# RFGate 3.2.T

Transmitter for safety edges to RFGate 3 wireless signal transmission system

# Supplementary sheet to the original instruction manual

## General

Intended use: In combination with a receiver RFGate 3.x.R



### **1** Safety instructions

(i) Battery life up to 2 years, but it is recommended batteries are changed every 12 months.


#### 2 Wiring / set-up

### 2.1 DIP switch setting

DIP switch setting according to sensors (safety edge, switch contact)

 $\bigcirc$  Conductor cross section 0.25 – 0.75 mm<sup>2</sup>

on RFGate 3.2.R




# \* IN2 is only active when used with dual channel receiver RFGate 3.2.R with DIP switch 2 OFF

How to change inputs from NC to NO (factory setting = NC) 2.2 1. 2. 3. 1.5 sec. Insert first Status Change 2x = NCNC 🔶 NO battery 4x = NOLED flashes Press button on Status LED flashes transmitter changes 4. 5 Change stored After inserting the first battery, Insert 2<sup>nd</sup> (i) battery you have 10 seconds to change the logic.

#### Cable routing, strain relief 2.3

- ① Determine the cable routing
- (2) Break out the corresponding part of the cover if necessary

- (4) Thread cable
- (5) Fix cable with the clamp ( $\rightarrow$  strain relief)
- (i) Cable Ø: 3.1 5.2 mm



BBC Bircher Smart Access, BBC Bircher AG, Wiesengasse 20, CH-8222 Beringen, www.bircher.com Designed in Switzerland / Made in EU